

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5A

PRINT		PROPERTY (P)	
PRINTER	ABC Laser 5000		
PRINTER NAME (N)	IDLE		
STATUS	ABC Laser 5000		
TYPE			
COMMENT			
		<input type="checkbox"/> PRINT TO FILE (L)	
PAGE RANGE		SUPER USER MODE (JOB SECURITY)	
<input checked="" type="radio"/> ALL (A)		PASSWORD	
<input type="radio"/> CURRENT PAGE (E)		JOB CANCELLATION <input type="radio"/> JOB OUTPUT <input type="radio"/>	
<input type="radio"/> PAGES (G)			
ENTER PAGE NUMBERS AND/OR PAGE RANGES SEPARATED BY COMMAS, FOR EXAMPLE, 1, 3, 6 OR 4-8			
PRINT WHAT (W)	DOCUMENT	PRINT (R)	ALL PAGES
OPTION (O)			OK
		CANCEL	


WHEN DRIVER IS ACTIVATED

FIG. 5C

PRINT		[?] [X]	
PRINTER		PROPERTY (P)	
PRINTER NAME (N)	ABC Laser 5000		
STATUS	IDLE		
TYPE	ABC Laser 5000		
COMMENT			<input type="checkbox"/> PRINT TO FILE (L)
PAGE RANGE		SUPER USER MODE (JOB SECURITY)	
<input checked="" type="radio"/> ALL (A)		PASSWORD	*****
<input type="radio"/> CURRENT PAGE (E)		JOB CANCELLATION	<input checked="" type="radio"/> JOB OUTPUT <input type="radio"/>
<input type="radio"/> PAGES (G)			
ENTER PAGE NUMBERS AND/OR PAGE RANGES SEPARATED BY COMMAS, FOR EXAMPLE, 1, 3, 6 OR 4-8			
PRINT WHAT (W)	DOCUMENT	PRINT (R)	ALL PAGES
OPTION (O)		OK	CANCEL

WHEN "JOB CANCELLATION" IS SELECTED

FIG. 6



007027" 2249260

FIG. 7

JOB SECURITY STATUS SHEET

No.	USER NAME	DATE OF RECEPTION	FILE CAPACITY(kB)
1		'99.10.25 10:35	10
2	AAA	'99.10.25 14:15	25
3	BBB	'99.10.28 9:12	68
4		'99.10.28 21:35	100
5	AAA	'99.10.29 22:00	76
6	CCC	'99.10.31 13:05	89
7	DDD	'99.11.1 9:58	84
8	EEE	'99.11.2 10:35	1
9		'99.11.11 18:58	325
10	BBB	'99.10.15 10:35	145

007027" E2492/60

FIG. 8

